

## **Zoom Function**

The Double Barrel Blood Tracker Zoom<sup>®</sup> uses two specialized LED diodes. These diodes emit wavelengths in the red and a green light spectrum.

The patented zoom function allows the user to control the intensity of the red and green lights independently. Adjusting the zoom of the red and green diodes varies blood reflectance and blood contrast. This permits the blood tracking abilities to be optimized for a variety of terrain, adjust for age of blood and compensate for differences in individual user eyesight.

The unit's red diode controls a blood trails reflectance or how brightly the blood glows.

The green diode increases or decreases a blood trails contrast with the surrounding environment.

An extreme example would be a blood trail in snow vs. a blood trail in fall forest leaf litter. The blood trail in snow would need less green light to stand out from the white background than the blood trail in fall forest leaf litter. Fall leaf litter often contains reds, browns, and other colors similar to that of blood and therefore the green diode should be zoomed to its widest extent to make blood stand out from these background colors.

**To increase bloods reflectance, intensify the red light by pulling the zoom of the red diode away from the light body. This concentrates and intensifies the red wavelength.**

**To increase the bloods contrast with the surrounding terrain intensify the green light by pulling the zoom of the green diode away from the light body. This concentrates and intensifies the green wavelength.**

The Double Barrel Blood Tracker Zoom<sup>®</sup> is able to create an infinite number of combinations of red and green diode intensities. The optimal ratio of red to green wavelengths varies and is dependent on many factors such as terrain, age of blood, and individual user eyesight. Like any tool it will take the user a little practice to adjust to his or her individual needs.

We find it is best to start off with both the red and green diodes at the lowest zoom or light intensity

This is accomplished by making sure both the red and green zooms are up against the main body of the light. This also has the advantage of covering the widest possible search area. When a blood trail is found the user then adjusts each of the lights independently until the optimal reflectance and contrast is found.

Upon finding a blood trail:

- 1) Pull the green zoom slightly out concentrating the green wavelength and the blood contrast.
- 2) Pull the red zoom out slowly until the optimal blood reflectance is found.

The trail is then followed and the game animal is recovered.

It is not recommended to start with both zooms pulled out. This light intensity is most often too bright and will wash out the blood trail.

## **Batteries**

2 AA alkaline, Nicad or lithium ion batteries are needed.

## **Maintenance**

During the off season store your Double Barrel Blood Tracker Zoom® in a cool dry place away from direct sunlight without batteries. This prevents the possibility of battery leakage and associated corrosion.

Once per year, threads should be wiped with a clean cloth followed by a thin coating of silicon-based lubricant.

## **Warranty Information**

All Double Barrel Blood Tracker Zoom® lights are warranted for product quality. Any defective / malfunctioning Double Barrel Blood Tracker Zoom® product can be repaired free of charge for a period of 12 months (1 year) from the date of purchase. Beyond 12 months (1 year), a limited warranty applies, covering the cost of labor and maintenance, but not the cost of accessories or replacement parts. The warranty is nullified in all of the following situations:

1. The product(s) is/are broken down, reconstructed and/or modified by unauthorized parties.
2. The product(s) is/are damaged through improper use.
3. The product(s) is/are damaged by leakage of batteries.

For the latest information on Double Barrel Blood Tracker Zoom® products and services, please contact your local Double Barrel Blood Tracker Zoom® distributor or send an email to [service@glohound.com](mailto:service@glohound.com)



Get Your Game!

## DOUBLE BARREL BLOOD TRACKER Z® User Manual

### Features

- Designed for the hunter needing to track wounded game in low light in any habitat
- The only blood tracking LED flashlight to feature a patented zoom function
- Allows for adjustment of light intensity to control blood reflectance and contrast
- Red light only mode for night time map reading
- Uses high powered GREE LED diodes for 10w of total power
- Constructed of aerospace-grade aluminum body with anti-scratching type 3 hard anodization
- Toughened clear resin convex lenses
- Shockproof and water resistant

### Switching ON/OFF and Adjusting Output

The Double Barrel Tracker Zoom® is turned on and off by pressing the orange buttons located at the end of each side.

